

Installation Quick Start Guide for WSP04 Important Installation Instructions

- 1 Turn off inlet and outlet valves.
- **2** Open the drain on the gate valve in order to relieve the pressure from the filter.
- **3** Turn the filter cartridge counter clockwise to uninstall.
- **4** Install the new filter cartridge by rotating it clockwise until it is firmly in place. Do not over-tighten.
- **5** Turn on inlet valve and run air through the gate valve until you start receiving water.
- 6 Close the drain and open the outlet valve. Check for any leaks at this time.
- 7 Check the filter for leaks over the next 24 hours.

For further questions or assistance please call (866) 218-8473.

 Warning: To reduce the risk of property damage due to water leakage, this filter MUST be installed in accordance with the manufacturers specifications and instructions. This filter unit must be replaced every 6 months, at the rated capacity, or soner if reduced water flow occurs. Protect from freazing. Failure to follow instructions and operating specifications will void your warranty. Further, manufacturer assumes no responsibility or lability for damages arising out of misuse of the product.

 Do no use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before and/or after the filter. For cold water applications only.

Aquamor, LLC, 42188 Rio Nedo, Temecula, CA 3/2020 www.watersentinelfilters.com P/N 803270